



1 Lay the Permo® extreme RS with a drape of 10 – 15mm between the rafters.



2 Pull off adhesive tape at the eaves adhering.



3 Fix 50mm Butylon® tape down the rafters to seal around any nail penetrations.



4 Install battens fixing nails through Butylon® tape and lay next layer of Permo® extreme RS with a 100mm headlap so adhesive strips meet.



5 Peel back adhesive tape on the two strips sticking the two together.



6 Fix battens and continue process until underlay installation is completed.

#### Klober Ltd

Unit 6F, East Midlands Distribution Centre, Short Lane, Castle Donington, Derbyshire DE74 2HA  
T: 01332 813 050 · F: 01332 814 033 · [info@klober.co.uk](mailto:info@klober.co.uk) · [@KloberLtd](https://twitter.com/KloberLtd)

# KLOBER