



**Natural Range
Dry Verge System**

Components



All fixings available separately

Step 1



Images show installation of Right Hand units

Cut the tiling battens to overhang the verge by 45mm. The underlay must not extend more than 10mm past the verge.

Step 2

Position the eaves course tile and locate the **Natural Dry Verge Unit** over the tile. Insert the **Natural Eaves Stop End** and mark the position.



**Natural Range
Dry Verge System**

Step 3

Remove the tile and **Natural Dry Verge Unit** and secure the **Natural Eaves Stop End** with a **Drive Screw Nail**.



Step 4




Place the **Natural Dry Verge Unit** on the tile and slide them down onto the **Eaves Stop End** ensuring that the fin has engaged.

Step 5

With the back of the **Natural Dry Verge Unit** pressed firmly down, nail through the appropriate hole with a **Drive Screw Nail**.

Repeat instructions 1 – 5 for the opposite verge (if present)



Natural Range Dry Verge System

Step 6


Lay the next tile at the verge and fix as per the Fixing Specification*.

To secure subsequent **Natural Dry Verge Units**, first slide it onto the previous **Natural Dry Verge Unit** until the front lip drops over the tail of the verge tile and ensure that the fin is engaged and secure.

Press the back of the unit firmly down and nail through an appropriate hole.



Step 7



Repeat instruction 6 for all subsequent courses before then laying the ridge system and ridge tiles.

Step 8

Finish off the ridge with a Russell **Natural Range Ridge End Cap** to suit the ridge profile and tile type.

Gauge the depth of the ridge tree batten and secure with a **Drive Screw Nail** through the appropriate hole.

Alternatively a Russell **Block End Ridge** can be used and secured using the supplied fixings.



**Natural Range
Dry Verge System**

Notes

- Maximum gauge: 343mm. Minimum gauge: 273mm
- For split stone/brick verges excessive gapping may occur and a bird comb filler should be installed (supplied separately)
- For masonry verges an alternative fixing method is required – Please contact Russell Technical Department
- When used on rigid sarking boards please contact the Technical Department for advice on installation
- Where wraparound guttering is used please contact Russell Technical for fixing advice
- For fixing into non timber materials please contact Russell Technical
- The roof pitch must not exceed more than 45°
- Battens used are to comply with BS5534:2014
- When using Russell's dry verge the system counts as one of the two required perimeter fixings.